



UNIVERSAL DECAP DIE

The decap pin should extend approximately 1/4" below the bottom of the die. Screw the die into the press until there is a gap between the bottom of the die and the shell holder of about 1/16" when the press ram is in the "up" position. Set the die lock ring and you're ready to decap.

WARNING:

Do not decap live primers!

Customer Service

1-800-533-5000 (US or Canada) or **530-533-5191**

Hours: Monday - Friday, 6:30am - 4:00pm Pacific Time

e-mail: rcbstech@atk.com • www.rcbs.com

RCBS • 605 Oro Dam Blvd. • Oroville, CA 95965

CCI • SPEER • RCBS

OUTERS • RAMLINE • ORBEX • FEDERAL